



T1 monowing

For your first few sessions, we recommend you ride the T1 in moderate, not light wind speeds. When you are water starting and up riding it is important to align your back foot with where the leading edge of your masts intersects with the board.



This will control the wing's pitch and allow you to enjoy easy starts and riding from the get-go!


The T1 likes a lot of wind so don't be afraid to ride it with a smaller kite.

Setup

T1 monowings sold without the mast set come with this pedestal washer to protect the carbon fiber and improve the connection. Do not use it without this washer.



And the T1 comes with a square slot washer. This washer prevents the slot screw from digging into the slot resin, coming loose, or bending. Do not use it without this washer.



T1's sold with a mast set, come with a this slot washer which does the same as the square washer but is designed for the Moses adapter and our mast only. It will not fit any other masts. Do not use it for other masts.



Cautions:

1. Make sure you tighten the two M8 bolts attaching the wing to the mast using a decent amount of force. Before each new session check the bolts to make sure they are tight. This will ensure the mast and wing are rigid and ready to ride!
2. The T1 is designed for freestyle riding and cruising. It enjoys low-level aerial maneuvers like backrolls but is not warranted for jumping at height. **Warning:** repetitive jumping will irreparably damage the wing and make it impossible to ride.